



HOTCHKIS
HOTCHKIS
SPORT SUSPENSION



Anti-roll bar set (pn 2278)
Pontiac GTO



Thank you for your purchase from our new line of GTO parts.
Please call us at (877) 4NO-ROLL if you have any questions
regarding the service or installation of your Hotchkis Performance products.
Visit us online @ www.hotchkis.net

Warning: This installation should be performed by a trained professional. The installation requires lowering of the front & rear cradle frame from the vehicle for swaybar removal and reinstallation.

INSTALLATION OF HOTCHKIS FRONT SWAY BAR

Tools Required for this Installation

- 4 post lift or alignment rack with center jacks
- Transmission jack
- Pry bar
- The following sockets or wrenches: 6mm, 8mm, 13mm, 14mm, 18mm


Tools to temporarily block/plug transmission cooling lines

- 2 hose pinch-off pliers, 3/8" hose (about 12" long), 2 7/16" bolts (about 1" long)


- 1) Drive the car onto the 4-post lift or alignment rack and securely block the rear wheels.




2) Remove the 4 bolts that secure the skid plate using a 13mm socket.




3) Next, disconnect the sway bar endlink from the bar using a 14mm socket or wrench




4) Support the cradle frame using a transmission jack.




- 5) You will now disconnect the cradle frame from the vehicle by removing the 2 front bolts and 2 rear bolts using a 16mm and 18mm socket respectively.



- 6) Slowly lower the transmission jack. The cradle frame will lower about 3-4 inches in the front. You do not have to worry about the cradle falling down since it is still connected to various other components e.g. control arms, engine/transmission etc. It may be necessary to raise the front of the car at the outer jack points using your center jacks in order to gain more clearance between the cradle and the car.
- 7) At this point, you will need to disconnect the coolant/transmission line brackets from the front of the cradle frame using a 8mm socket. There are 2 bolts on the driver side bracket and 1 bolt on the passenger side bracket.



You will notice that the hard transmission lines lay on top of the coolant/transmission line bracket mounts. Make sure to move the transmission lines below the brackets. This will allow the bar to pass through between the coolant lines on top and the transmission lines on the bottom.




- 8) This next step is where the messy stuff begins. As you can see from looking at the stock sway bar location, the bar will not be able to slide out while the transmission lines are connected. It will be required to disconnect the soft hoses from the hard lines. There are 2 lines that will need to be disconnected and blocked/plugged temporarily. To avoid spilling too much transmission fluid, use some hose pinch-off pliers to seal one soft hose at a time. Prepare yourself with your 3/8" hose and 7/16" bolts. Use the other hose pinch-off pliers to clamp down the center of the 3/8" hose. Loosen the hose clamp using a 6mm socket.


Then disconnect the soft hose from the hard line slowly. Once disconnected, connect the one end of the 3/8" hose to the hard line. Plug the soft transmission line with one of your 7/16" bolts. Once the bolt is in place you can release the pinch-off pliers from the soft transmission line.



Now, clamp down on the other soft transmission line. Loosen the hose clamp using a 6mm socket. Then disconnect the soft hose from the hard line slowly. Once disconnected, connect the other end of the 3/8" hose to the hard line. Insert the 7/16" bolt into the soft transmission line and release the pinch-off pliers. The end result should look like the following picture.



- 9) Before we can remove the sway bar from the vehicle, we need to disconnect the saddle brackets from the cradle. Use a 13mm socket to remove the 2 nuts per side. Once the bracket is out, remove the rubber bushing as well. You may discard the bracket and the rubber bushing, but keep the nuts for reinstallation.



- 10) The bar can finally be removed from the vehicle. The sway bar will have to come out through the front, but it will take some patience to do so. Try to pull the passenger side end out first as shown in the picture. Once that end is free you can pull the bar completely out. Please note the orientation and position of the stock sway bar for reference for the Hotchkis sway bar.




- 11) Place the Hotchkis sway bar next to the stock sway bar to setup proper orientation. This is done to avoid putting the sway bar in upside.
- 12) Next, insert the Hotchkis sway bar into the vehicle in the same fashion as the stock bar came out. This time insert the driver side first. You will notice the Hotchkis sway bar will be easier to insert into the car than the stock bar coming out.




- 13) After the bar is in position, lube the inside hole of the Hotchkis polyurethane bushings with the included grease.



14) Open the bushing and push it over the bar. Make sure the flat side is facing up and the split is in the front.




15) Next, grab the Hotchkis saddle bracket and place it over top the bushing. Make sure the zerk grease fittings are pointing toward the front (ignore zerk fitting position in picture). Install the stock nuts using a 13mm socket.



16) Repeat steps 2-9 in reverse order to complete the front installation.

Special tip: Use a large pry bar when trying to re-align the cradle frame holes with the body. You want to be able to start each bolt by hand first.

- 17) When reattaching the endlinks onto the sway bar, you will notice 3 holes at the end of the bar. Your Hotchkis swaybar is 3-way adjustable for stiffness. See the following diagram for details.



- 18) You are now finished with the Hotchkis front sway bar installation! Make sure that all hardware is fully tightened. On to the Hotchkis rear sway bar installation.



HOTCHKIS
HOTCHKIS
SPORT SUSPENSION



INSTALLATION OF HOTCHKIS REAR SWAY BAR

Tools Required for this Installation

- 4 post lift or alignment rack with center jacks
- Pry bar
- Transmission jack
- The following sockets or wrenches: 13mm



- 1) Drive the car onto the 4-post lift or alignment rack and securely block the front wheels.



- 2) Support the Rear differential using a transmission jack or a center jack equipped on some 4-post lifts.



- 3) Remove the 4 bolts that secure the backside of the rear differential housing.




- 4) Slowly lower the transmission jack and let the differential and rear cradle frame tip downward.



- 5) Next, detach the endlinks from the sway bar using a pair 13mm wrenches.



- 6) Undo the saddle brackets by removing 1 bolt per bracket using a 13mm socket. Simply rotate the bracket up and it will become detached from the cradle frame.



7) Remove the stock sway bar from the vehicle through either side of the differential.



8) Set the Hotchkis sway bar next to the stock sway bar for proper orientation.




- 9) Lube the inside hole of the Hotchkis polyurethane bushings with the included grease.



- 10) Open the bushing and push it over the bar. Make sure the flat side is facing down and the split is facing toward the front.



- 11) Place the stock saddle brackets back onto the Hotchkis polyurethane bushings.




12) Reinsert the Hotchkis sway bar in the same manner as the stock bar came out.

13) Repeat steps 2-6 in reverse order to complete the installation.

Special tip: When raising the differential back up to the body, try using a pry bar to align the mounting plate holes with the body holes. You want to be able to start each bolt by hand first.

17) When reattaching the endlinks onto the sway bar, you will notice 4 holes at the end of the bar. Your Hotchkis swaybar is 4-way adjustable for stiffness. See the following diagram for details.



18) You are now finished with the Hotchkis rear sway bar installation! Make sure that all hardware is fully tightened before driving the vehicle.



HOTCHKIS
HOTCHKIS
SPORT SUSPENSION



Anti-roll bar set (pn 2278)
Pontiac GTO

	Hotchkis P/N	Item Description	Quantity
1	22800286	Front Anti-Roll Bar	1
2	22900286	Rear Anti-Roll Bar	1
3	23890286	Front Saddle Brackets	2
4	21810286	Front Bushings	2
5	21910286	Rear Bushings	2
6	90_Zerk	90° Zerk Fitting	2
7	9.11108	Grease Pack	2



All information contained herein is subject to change without notice. BUYER'S ACCEPTANCE OF DELIVERY OF THE PRODUCT CONSTITUTES BUYER'S ACCEPTANCE OF THE TERMS HEREIN. ANY ADDITIONAL OR DIFFERENT TERMS PROPOSED BY THE BUYER ARE HEREBY REJECTED IN THEIR ENTIRETY UNLESS EXPRESSLY AGREED TO IN WRITING BY SELLER'S AUTHORIZED AGENT.

TERMS

Prepaid, Visa, MasterCard. Net 30 days from invoice date terms are available after credit approval. Accounts with invoices past due will be placed on "Credit Hold". A finance charge of 1.5% per month will also be applied to all past due invoices, not to exceed the maximum charge permitted by law. Accounts are considered paid in full upon Hotchkis Performance Inc.'s receipt of the full invoice amount plus collection fees and expenses incurred, if any. NSF checks stop payment checks, chargebacks on credit cards, etc. are charged a minimum of \$35 fee. No deduction or credit may be taken for any reason unless a credit memo has been issued by Hotchkis Performance Inc. Any unauthorized deduction will automatically put the account on credit hold. Other product special orders require a 50% down payment and are also non-cancelable and non-returnable.

DROP SHIPMENTS & REFUSED PACKAGES

Drop shipments are charged a \$30 service charge. A 20% restocking fee and all shipping costs are charged to the ordering party if a package is refused. No international drop shipments.

RETURNS

All returns are subject to prior authorization from Hotchkis Performance Inc. Once authorized, a Return Merchandise Authorization (R.M.A) will be issued. All authorized returns must have the R.M.A number on all cartons and shipping documents. Returned product must be shipped prepaid – collect shipments will be refused. Modified or used products are not eligible for return. Returns **MUST** be made within 90 days of invoice date and are subject to a **20% restocking fee. No returns are accepted after 90 days.** Freight charges are not refundable unless the merchandise is defective as determined by Hotchkis Performance Inc. Special orders are not returnable.

DAMAGED SHIPMENTS / SHORTAGES

All Hotchkis Performance Inc.'s shipments are F.O.B. our factory. Title passes from Hotchkis Performance Inc. to the purchaser at the time is shipment initiated. Claims for Carton shortages and damages must be made against the carrier at the time of delivery. To expedite processing of claims against the carrier, the customer must note damages on the bill of lading at the time of the delivery, and promptly request an inspection by the carrier or its claims agent. If a shortage is found within the shipment, it must be reported to Hotchkis Performance Inc. in writing within five (5) business days of receipt of shipment. Claims need to include the following information order number, invoice number, date of invoice, date of shipment, part number, description and carton count.

PRODUCT SUBSTITUTION / OTHER

Hotchkis Performance Inc. reserves the right to substitute equal or better materials or products at its discretion. Hotchkis Performance Inc. reserves the right to change specifications and other information included in this catalog without notice. All information, data and dimension tables in this catalog have been carefully compiled and thoroughly checked. However, no responsibility for errors or omissions can be assumed. Some parts may not be legal for sale or use in certain states, including California, on certain pollution-controlled motor vehicles. It is the purchaser's responsibility to determine if any parts they purchase are suitable for their particular locale and use.

WARRANTY / DISCLAIMER

Hotchkis Performance Inc. warrants that the products will be free from defect in material and workmanship for three years from date of sale to the original purchaser. Hotchkis Performance Inc. makes no other warranty of any kind, express or implied. Hotchkis Performance Inc. shall have no obligation under the forgoing warranty where the defect is the result of improper or abnormal use, user's negligence, vehicle accident, improper or incorrect installation or maintenance, nor when the product has been repaired or altered in any way. Hotchkis Performance Inc.'s liability in the case of defective products subject to the forgoing warranty shall be limited solely to the repair or replacement, at Hotchkis Performance Inc.'s option, of the defective products. Hotchkis Performance Inc. will be the sole judge of the validity of warranty claims.

Consequential or incidental damages are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

In order to be eligible for service under this warranty, the defective part(s) must be returned to Hotchkis Performance Inc. by the original purchaser together with the R.M.A number issued from Hotchkis Performance Inc. and a copy of the receipt showing purchase within past 3 years. Tag each item with the part number and the specific explanation of defect. We will inspect the part and determine: a) if it is eligible for repair or replacement; and, b) if so, whether to repair or replace it. All returns must be shipped **prepaid** to:

Hotchkis Performance Inc.
RMA # _____
118 Infield Court
Mooresville, NC 28117

Hotchkis Performance Inc. will return all products covered under warranty to you by ground freight at Hotchkis Performance Inc.'s expense. Any expedited freight is the responsibility of the customer.

THE BUYER UNDERSTANDS AND EXPRESSLY RECOGNIZES that ALL parts and services sold by Hotchkis Performance Inc. are exposed to many and varied conditions due to the manner in which they are installed and used. BUYER ACKNOWLEDGES that HOTCHKIS PERFORMANCE INC. does not have full knowledge of the intended use of goods, and BUYER WILL DEFEND AND INDEMNIFY HOTCHKIS PERFORMANCE INC. upon demand against all claims, actions, liability, loss and expense (including investigating expense and attorney fees incurred in litigation or because of threatened litigation) for any loss, damage or injury, either to a person or to property, resulting from the direct or indirect use of any Hotchkis Performance Inc. products or inability by the buyer to determine proper use or application of Hotchkis Performance Inc. products. With the exception of the limited liability warranty set forth above. Hotchkis Performance Inc. SHALL NOT BE LIABLE FOR ANY CLAIMS, DEMANDS, INJURIES, DAMAGES, ACTIONS, OR CAUSES OF ACTION WHATSOEVER TO BUYER ARISING OUT OF OR CONNECTED WITH THE USE OF ANY HOTCHKIS PERFORMANCE INC. PRODUCTS

MOTORSPORTS AND SIMILAR ACTIVITIES ARE DANGEROUS; AS SUCH, NO WARRANTY OR REPRESENTATION IS MADE AS TO THE PRODUCT'S ABILITY TO PROTECT THE USER FROM INJURY OR DEATH. THE USER ASSUMES THAT RISK