

25117

C7 Corvette

Adjustable Sway Bar End Links

*Thank you for your purchase from our new line of Chevy parts.
Please call us at 877 - 4NO - ROLL if you have any questions
regarding the service or installation of your Hotchkis Performance products.*

Factory End Link Center to Center Length: 3.2" (81mm)
Hotchkis End Link Center to Center Range: 3.2" (81mm) - 3.6" (91mm)



Installation Instructions:

1. Drive the vehicle onto an alignment rack or similar to access the car from underneath at operating ride height.
2. Remove the factory end links from the vehicle.
3. If you are going to corner balance the vehicle, now is the time to do it. (optional)
4. Once the vehicle is at the intended ride height, Install one end of the end links to either the control arms or sway bar ends. Keep the jam nuts loose for now.
5. Insert the remaining loose end of the end link onto sway bar or control arm. If there is any preload, adjust the end link lengths so the end links insert into the holes without any binding. Tip: Try to keep the end links as short as possible.
6. Make sure the male and female ends are pointing 180° from each other and tighten the Female end and Jam nut. Do not over tighten.

Note: The threaded stem is thread locked into the shorter end to create a "male" end. The threaded stem should never be unthreaded from this end.

